## SLIM DUCT SERIES DRAIN PUMP INSTALLATION MANUAL

## ■ Drain pump Fitting List

DB68-03727A(2)

	•			` '
Drain Pump(1)	Plug(1)	Sponge Sealing	Heat Insulation	Flexible
		Strips(1)	Protection	Drainage
1				

■ Drain pump Installation Steps				
Installation Manual	Installation Step	Installation Schematic Diagram		
	1-1 Unscrew two screws of the box cover and open the box cover.	50 O		
	1-2 Strike the graphical side board on all sides with tool, and remove of the side board.(wherethe drain pump is installed)	500		
Drain pump Installation	1-3 Shown as the figure,the drain pump connection line passes therough the hole to the position of the control box.			
	1-4 Align to the position and install the drain pump.			
	1-5 Use 4 screws to fix the cover board of the drain pump.			

Installation Manual	Installation Step	Installation Schematic Diagram
	2-1 Drain pump wire connection.  The port of the drain pump boday connection wire is yellow.  The port of float switch connection wire is black.	
Wire Connection and Swith Setting	2-2-1 Setting an indoor unit installation option (SEG 8) 2-2-2 Drain pump(SEG8) will be set to 'Disuse' 'Use' and 'USE+3minutes delay'.  Note:Option is defined as follows. 0.Disuse 1.Use 2.When an indoor unit stops, drain pump will operate for 3 minutes.	SAMSUNO
Š	2-3 Bundle up the drain pump connection wire.	
	2-4 Install the cover board of the control box.	

Installation Manual	Installation Step	Installation Schematic Diagram
	3-1 Install the drain hose,tighten it with a screw driver. About its installation, Refer the installation of the hose.	MINING IN COLUMN TO THE PARTY OF THE PARTY O
	3-2 Wrap the drain hose by sealing sponge.	
Drain Hose Installation	3-3 Insert the drain hose with an insulated protective tube.	
	3-4 Strap it by tie.	

Installation Manual	Installation Step	Installation Schematic Diagram
Block the drain	4-1 Insert the chock plug into end of the drain hose on the water basin. In order to avoid leakage,make sure to install the chock plug.After installing,its end must be close to end of the drain hose.	See
hose	4-2 Wrap end of the drain hose by sealing sponge,and strap it by tie.	
	5-1 Unscrew 3(or 5)screws to open the test cover.	
Drainage test	5-2 Inject water to the water basin, check operation state of the drain pump.After installing the drain pump,make sure to test drainage, so as to avoid unsmooth waterway and prevent overflowing of water from the indoor unit.	
$\wedge$	•The drain pump must be installed by an installation specialist.	



- ·Before installation,ensure that you have turned off the main power.
- ·The draining pump must be equipped with the products specified by the Company.
- ·In case of any claim due to unauthorized modification of the draining pump,the Company shall assume no liability.